

All EnerSys batteries include serial numbers for manufacturing traceability and warranty processing.

To assist the field in the proper serial number label identification, the following guidance is provided.

Serial numbers are alpha-numeric, printed on labels and can come in a variety of forms as shown below.







The location of the serial number label also can vary as shown below.



If you don't see the serial number label in the location you are used to seeing it, please refer to the other locations shown above to find it.

Direct any questions to warranty@enersys.com or call 1-800-964-2837.